LIGHTING SYSTEM

PRECAUTION

1. PRECAUTION OF HEADLIGHT BULB REPLACEMENT

- (a) If even a thin film of oil is left on the surface of the halogen light, its service life will be shortened because the light will burn at a higher temperature.
- (b) Handle any halogen light with great care. Dropping, hitting or damaging the bulb in any way may result in exploding and shattering it because the internal pressure is high.
- (c) Always prepare a new bulb for immediate replacement. While replacing the bulb, the lens may attract dust and moisture if removed from the vehicle for too long.
- (d) Always use a bulb of the same wattage for replacement.
- (e) Firmly reinstall the socket after bulb replacement. The lens may become cloudy or the light cavity may fill with water through the gaps around the socket.